

54mm
324mm

54mm

WAVEFUN


V

TWS Wireless Earbuds

User Guide

www.wavefun.net

Start-up



- ① Multi-function key
- ② Microphone
- ③ Charging port
- ④ LED light
- ⑤ Charging pin

How to Connect

A: Connect double earbuds
Take out the both earphones out of the charging case, then turn on the Bluetooth function of the mobile phone, search for "Wavefun V" to connect.

B: Connect single earbud
Take out R or L earphones out of the charging case, then turn on the Bluetooth function of the mobile phone, search for "Wavefun V" to connect.

Note:

1. The earbuds will remember previously paired devices and will attempt to pair with the last connected device automatically.
2. You can switch the left or right earphone as the main earphone.

Tips: The earphones will remember previous paired device and will attempt to air with it automatically

How to Charge

Low battery will be warned by voice, just put the earphones back into the charging case and close the case, the bottom indicator light of the charging case is always on orange color during charging, and it will be off after been full charged.

Charge for the dock

Please charge the charging case with the Micro usb cable included in the box, and you can know the remaining power of the charging case by the indicator light on the bottom.

Flicker times each 2 seconds	Remaining battery percentage
1	0-25%
2	25-40%
3	40-55%
4	55-100%

Tips: when the indicator light on the top flicker white color after you open the charging case, it means the battery capacity of the charging case is less than 25% and you need to charge it.

Function & Operation

Power On/Off

Power On: Open the charging case, the earphones will power on automatically. (if your earphone is not in the charging case or the charging case battery run out, then press the multi-function key of both R and L side earphones for 2 seconds to power them on)

Power off: put the earphones back to the charging case and close the upper case. (if you want to press buttons to turn it off, then press the multi-function button for 6 seconds, it will be powered off after the orange light on for 1 second)

Tips: the left earphone is the master, the earphone will be powered off without connected for 10 minutes.

Next Track

When playing, Long press the right earphone for 2 seconds to previous song and long press the right

earphone button for 2 seconds to next track.(it only supports next track for mono mode.)

Activate Siri

Double press right or left earphones to activate or close IOS siri function, while the earphones are under standby or music playing mode.

Play/Pause

When playing music, Press right or left earphones once to pause and press it again to resume playing.

Calling Switching mode

During the phone call, Long press right or left earphones for 2 seconds to switch between earphones and mobile phone.

Answer/End a Call

Press R or L side multi-function button to answer incoming call, or press the button for 2 seconds to reject it.

End a call

Press R or L side multi-function button to end a call.

Reset the earphones

Make sure the earphones powered off, then long press right and left earphones for 15 seconds until the light flash orange and white for 1 second, then power on the earphones again, and press the Multi-function button of both R and L side for twice then R and L will be paired. The LED light will flicker orange and white color alternately.

Master /slave mode

Wavefun V supports master/slave switch function.

1. Open the charging case and take out R or L earphones out, connect with mobile phone, if taking another earphone out, then R and L will be paired itself.
2. When the master earphone is powered off or put the master earphone into charging case, then the other earphone will be changed to be the mater earphone.

Item Parameters

Model Number: Wavefun V Bluetooth Version: 5.0
Waterproof : IPX5 Operation range : 10meters
Music time: 3-4 Hours Processor: Airoha AB1536U
Charging case battery capacity: 500mAh
Input Voltage: DC 5V (please charge it with the original 5V 1A charging case included in the box)

Tips: Playing time varies according to volume level and audio content.

Troubleshooting

Q: The earphones cannot be paired with mobile phones

A: Make sure the earphones are fully charged;
Make sure the earphones are powered on;
Make sure the earphones are not paired with other devices;
Make sure the mobile phone Bluetooth functions is on;
Make sure the distance between earphones and mobile phone are in connectable range.
If the above stops cannot help to solve the problem, please try to reset it.

Q: The earphones do not work, or no any response when you press the button

A: Long press and hold the multi-function button of the earphones and put them into the charging case to charge. Then release the button and close the charging case.

Tips

1. Before using the earbuds, please read the manual carefully and keep it for future references.
2. The earbuds need to be fully charged prior to first-time use.
3. If the earbuds are left unused for over two weeks, please recharge it periodically.
4. If the earbuds can't be searched by your Bluetooth device, please check whether it's in pairing mode. The earbuds will exit pairing mode if left unconnected for along while. If a procedure error of your phone occurs, reboot it, if a procedure error of the earbuds occur, reboot or reset it.
5. Please ensure using the proper size of eartip. If use unsuitable eartip, the earbud may not fit in the ear well. That may also has an influence on audio quality. Overcharging or keeping the earbud in a closed car or similar environment for a long periods will reduce the capacity and life of the battery. It is not recommended to charge the earbuds overnight.

Safety and Care

1. Never disassemble or modify your earbuds for any reasons to avoid any damages and danger.
2. Do not store the earbuds in extreme temperatures (under 0°C or over 45°C).
3. Avoid using the indicator to the eyes of children or animals.
4. Do not use this item during a thunderstorm to avoid irregular function and increased risk of electric shock.
5. Do not use harsh chemicals or strong detergents to clean the earbuds.
6. Keep the earbuds dry.
7. Please arrange using time properly since your hearing may be damaged by using the device for a long time.

Warranty

We guarantee every product has undergone rigorous tests prior to shipping. We are so confident in the quality of our products that we offer a one year warranty from the date of purchase.

 **Happy**

We're just happy that you're happy. If you don't know how to express your new found joy, we've got a few suggestions:

-  Tell your friends and family
-  Share your experience by writing a review on Amazon or AliExpress
-  Follow us on facebook by scanning QR code



 **Not Happy?**

Our friendly customer service team will work hard to put a smile back on your face. Here's how to contact us:

WAVEFUN Support
Support@wavefun.net

PE ♻️ CE III